


Fractionation of oils and fats



Why and How?

John Harris, Process Engineering Group Manager
Loders Croklaan, member of the IOI Group



Why? --- eg. Fractions from palm oil give added value!!




How? --- Fractionation Process principles




Importance of Solubility, eg. PPP in Palm




Crystallisation Processes




1' nucleation ---- birth of new small crystals



growth ----- size of crystals increases



agglomeration --- crystals stick together



attrition ----- agglomerated crystals break into small pieces, 2' nucleation

“Theory” of crystallisation



Supersaturation σ

$$\sigma = \frac{c - c^*(T)}{c^*(T)}$$

Primary nucleation rate

$$\frac{dN_P}{dt} \approx k_{np} \times 10^{\frac{-A_{np}}{(\log(1+\sigma))^2}}$$

Secondary nucleation rate

$$\frac{dN_s}{dt} \approx K_s \times M^a \times \sigma^b \times N^c$$


K, A, a, b, c:	constants,
M:	crystal mass
N:	stirring rate and type

Approximate crystal mass growth rate

$$\frac{dm}{dt} \approx \sigma^k * N$$


N: No. of nuclei or crystals per unit volume

Step-wise cooling




- Step-wise cooling.
 - Coolant inlet temperature is changed following time program
 - Crash cooling is with one fixed coolant temp ie. one step!

Delta cooling



- Delta cooling.
 - Maintain delta between slurry temperature and average coolant temperature.

Pre-cooling



- Oil feed is pre-cooled near to the temperature of heat of crystallization

Stirred Crystallisers eg.

- Lipico
- De Smet
- Alfa Laval
- Tirtiaux / JJ Lurgi
- and various other suppliers

Coil type crystalliser



IOI GROUP
Loders Croklaan



Tirtiaux style with Thermoplates



IOI GROUP
Loders Croklaan



De Smet concentric crystalliser



IOI GROUP
Loders Croklaan



Stirred crystallising slurry



IOI GROUP
Loders Croklaan



Static or Quiescent crystallisers

- De Smet
- Oiltek
- and others

Static crystallisation – cooled plates



IOI GROUP
Loders Croklaan



Quiescent crystallising in trays




IOI GROUP
Loders Croklaan




Quiescently grown crystal “slurry”



IOI GROUP
Loders Croklaan



Separation techniques



- Lipofrac with addition of water and detergent. Use of centrifuges for water (and crystals) from olein separation
- Florentine and rotary drum – now obsolete
- Membrane filter presses from 6 to 30 bar
- New use of centrifuges for crystals from olein
- Solvent slurry, filtration and washing with clean solvent

Separation efficiency (SE)

$$SE = \frac{SPC_{cake}}{100} = \frac{IV_{stearin} - IV_{olein}}{IV_{slurry} - IV_{olein}} \times \frac{SPC_{slurry}}{100}$$

$$Stearin \ yield \ \% = \frac{weight \ stearin}{weight \ slurry} \times 100 = \frac{SPC_{slurry}}{SE} \times 100$$

Separation efficiency strongly depending on

- crystallisation process
 - crystal size / size distribution / entrapped olein
- solid phase content of the slurry
- For membrane filter presses:

Pressure increase with time / maximum pressure / cake thickness




Membrane filter press



IOI GROUP
Loders Croklaan




Membrane filter press



Continuous separation with centrifuge

Westfalia Patented Process

The operation of a centrifuge is fully automated and easy to be handled.



Separation concept with centrifuge

Westfalia Patented Process

mass balance :


$$m_{\text{feed}} = m_{\text{olein}} + m_{\text{stearin}}$$

$$= m_{\text{light phase}} + m_{\text{nozzle}}$$


nozzle capacity constant :

$$m_{\text{nozzle}} = \text{const.}$$

$$m_{\text{olein}} = m_{\text{feed}} - \text{const.}$$




centrifuge => operation line



Solvent Fractionation: What if 75% crystals??




- Dry Fractionation




75%
crystals

Filter and press
for 75% SE




the
same

- with Solvent Fractionation



eg. 7.5 : 1
Solv:Oil

Filter and wash



< 80% yield of high
quality stearine



Fractionation is:-

- a Natural, Value adding, Physical oil modification process creating no undesirable byproducts
- From:
 - Simple, low stearine yields and low efficiency S/L separation
- To:
 - Sophisticated, high stearine yields and efficient S/L separation

Why? --- eg. Fractions from palm oil give added value!!

